



J A N U S e t C i e[®]

CARE & MAINTENANCE FOR FATA MORGANA

ACRYLIC

Acrylic comes in clear, frosted and different color options. It is an incredibly resilient material, but it should be handled with care. Special care should be taken when moving furniture with acrylic tops, as the acrylic can crack or break. Acrylics require very little maintenance; however, they can become scratched, smudged or dirty as with almost any smooth, hard surface.

ROUTINE CARE & MAINTENANCE

- Use Faron Cleaner (JeC Item #799-90-100-00-00) or mild, pH-neutral soap such as Dawn® and clean water
- Clean surface with a non-abrasive cloth or sponge
- Avoid rubbing dirt or grit into the surface
- Turn the cloth often and replace with a clean cloth frequently
- Dry by blotting gently with a clean, dry cloth
- Avoid the use of harsh or abrasive chemicals or ammonia-based cleaning solutions on the acrylic; these can eat into the sheet and cause it to craze

GLASS

Our tempered glass is a type of safety glass processed by controlled thermal or chemical treatments to increase its strength, and it is four times stronger than regular glass. We offer clear and ultra-clear sanded and painted glass that comes in different thicknesses, from 3/16 inch thick to one inch thick with a variety of edgework like flat polished and beveled edge.

CLEAR GLASS

ROUTINE CARE & MAINTENANCE

- Use a soft cloth and any normal household glass cleaning product such as Windex® to clean your clear glass
- You can also use mild, pH-neutral soap such as Dawn® and clean water
- Be careful of overspray and wipe off any fluid that gets on the frame

EXTENSIVE CARE & MAINTENANCE

- If stains persist, most can be removed by blotting the stained areas with a dampened soft cloth soaked with vinegar or lemon juice
- For light scratches, use a buffing compound such as car wax
- Using the buffer with 6,000 grit sandpaper, lightly buff the glass until scratches disappear

SANDED OR PAINTED GLASS

The sanded or painted side of the glass should always face down; it should never be used as the top (i.e. the work surface). This is because it can scratch, and also because stains and dirt on the sanded side are more difficult to clean than on the top side. Avoid the use of any sharp tools on the sanded top side of the glass.

ROUTINE CARE & MAINTENANCE

- Use a soft cloth and clean water to remove light dust or dirt
- For more persistent dirt and grime, use water mixed with mild, pH-neutral soap such as Dawn® and clean water
- Avoid abrasive or harsh chemicals on the sanded side; they can abrade and even remove the finish

EXTENSIVE CARE & MAINTENANCE

- If stains persist, most can be removed by blotting the stained areas with a dampened soft cloth soaked with isopropyl alcohol to remove residue or marks

HANDCRAFTED ARTISAN STONEWARE

Stoneware is a non-porous ceramic material which has been fired at a high temperature, making it strong and more resistant to chipping.

ROUTINE CARE & MAINTENANCE

- Wash with mild pH-neutral soap such as Dawn® and clean water using a non-abrasive cloth or sponge
- Don't use abrasive cleaners or scrubbers